


Contents & Features

- 1 MobileLite Wireless Unit
- 1 MicroSD Adapter
- 1 USB Cable (Type A to Micro B)



Download App

In order to access MobileLite Wireless from your mobile device (tablet, phone, etc.) you will need to download the MobileLite app.


1. Open Google play on your mobile device.



2. Search for '**Kingston**' in the search bar.



3. Install the '**MobileLite**' app by Kingston Digital.



Powering Unit On/Off


If the device is powered off, press and hold the power button for three (3) seconds or until the Power LED turns on. During the power-on sequence, the Internet (Bridge) LED may flash to initiate connection.

If the device is powered on, press and hold the power button for three seconds or until Power LED turns off.



Connect to MobileLite

1. Make sure the MobileLite device is powered on.
2. Wait for the Wi-Fi (Broadcast) LED to light up and become steady blue.
3. Go into the WiFi section of your mobile device.
4. Choose '**MobileLite Wireless**' from the list of wireless networks on your mobile device.



5. Go to applications on your mobile device.
6. Locate and open the MobileLite app.




Using the App



1. Tap the device name which is 'MobileLite Wireless' by default.

(This will list the current media that's inserted and detected by MobileLite Wireless.)




2. Select the media you wish to access. If you have an SD Card inserted, you will see 'SD_Card1'; if you have a USB device plugged in, you will see 'USB1'. In this example, both are listed, which indicates that both are currently available on the MobileLite Wireless unit.



A B C D E

- A. Displays current devices on MobileLite Wireless.
- B. Filters & displays all supported 'Photo' type content.
- C. Filters & displays all supported 'Video' type content.
- D. Filters & displays all supported 'Audio' type content.
- E. Drop down menu that brings up Search, New Folder, Settings, and Help

Device Settings



- F.** Default name of your MobileLite Wireless device. This is the SSID name that appears in the list of available wireless networks on your mobile device.
- G.** Battery life indicator.
- H.** Current firmware version of MobileLite Wireless.
- I.** Controls whether or not the SSID name will broadcast in the list of available wireless networks.
- J.** The wireless channel that MobileLite Wireless is currently using.
- K.** Controls whether or not users will be prompted for a password when joining the MobileLite Wireless network. The default setting is 'None'.
- L.** Allows you to bridge your MobileLite Wireless device to a secondary network. (See *Bridging*)

Bridging

Traditionally, the Wi-Fi antenna in your mobile device is used to access the Internet. However, since MobileLite Wireless is its own Wi-Fi network, it becomes the new primary network for your mobile device.


Bridging allows you to access the Internet after you've connected your mobile device to MobileLite Wireless by connecting to a secondary network. To do this, follow these steps:

Open the MobileLite Wireless app.



Tap the SSID name, which is MobileLiteWireless by default.

From the drop down menu, tap on 'Settings'.




Under '**Network Connection**', select the network you would use to access the Internet.

Note: If the selected network is protected by a password, you will need to supply it here in order for the bridging function to work.



Once you've connected and authenticated to the network:

1. A '*check mark*' will appear next to the network you chose, indicating that the bridging function is working properly -and-
2. The bridged LED will light up blue in color.



You can now stream content from the MobileLite Wireless network AND access the Internet.

Battery Backup

In addition to being its own Wi-Fi network, MobileLite Wireless can also be used as a battery backup. This feature allows you to charge a device, like a mobile phone or tablet, using the built-in USB port.

To use this function, follow these steps:




If the device is powered **on**, press and hold the power button for three seconds or until Power LED turns **off**.

Attach your mobile device to the USB port on MobileLite Wireless (*using its own Type-A USB power cable.*)

With MobileLite Wireless powered off, press the power button once and release; do NOT press and hold the power button, as this will turn the wireless broadcast function on.

Once the power LED begins to flash, the unit is ready and your mobile device should be charging.



(not drawn to scale)