Wi-Drive CD Updater

Wi-Drive CD Updater for Mac

System Requirements:

- Mac OS X 10.6.x – 10.7.x
- Admin (or user with administrative privileges)

(**NOTE**: **Before** running this CD Updater, it is strongly recommended that you make a back-up copy of the data content you have stored on the Wi-Drive device.)

During this procedure, you may be prompted to install a device driver. If so, please proceed with the installation of this driver (included in the Updater application) and reboot your system.

If you are **NOT** prompted for a device driver, please proceed to the section of this document entitled "*CD Update*" on page 6.

Device Driver Installation (Mac)

1. Connect the Wi-Drive to a USB port on your Mac system using the USB cable included with your device.

2. Double-click the Wi-Drive 'Updater' application (*Figure 1.1.*)

3. Click the 'Install' button when prompted to install driver (see *Figure 1.2* below.) ****NOTE**: Do **NOT** disconnect Wi-Drive during this step.

*Figure 1.1 - Updater*

Figure 1.2 – Device Driver Prompt

Device Driver Installation (…continued from page 2)

4. Click the 'Continue' button when the 'Installer' window appears (see *Figure 1.3.*)


Figure 1.3 – 'Driver Install' Installer window

5. Click the 'Continue' button when the 'README' window appears (see *Figure 1.4.*)

Figure 1.4 – 'README' window

Device Driver Installation (…continued from page 3)

6. Click the 'Install' button when the 'Installation Type' window appears (see *Figure 1.5.*)

Figure 1.5 – 'Installation Type' window

7. When prompted for a username and password, you must enter the name of a user with administrative privileges on your Mac, and then click 'OK.' This will allow the installer package to make the necessary changes to the system during the device driver installation.


Figure 1.6 – Prompt for Administrative Name and Password

8. Click the 'Continue Installation' button (seen below in *Figure 1.7.*)

Figure 1.7 – Continue Installation

Device Driver Installation (…continued from page 4)

9. Click the 'Restart' button on the 'Summary' window (seen below in *Figure 1.8*.) This will complete the 'Device Driver' installation and allow your system to reboot. After your system restarts, you will need to perform the 'CD Update' process by re-running the Wi-Drive 'Updater' just as you did in Step 1 of this section.

Figure 1.8 – 'Summary' window

– 'Device Driver Installation' Section Complete –

CD Update (for Mac)

(**NOTE**: **Before** running this CD Updater, it is strongly recommended that you make a back-up copy of the data content you have stored on the Wi-Drive device.)

1. Connect the Wi-Drive to a USB port on your Mac system using the USB cable included with your device.

2. Double-click the Wi-Drive 'Updater' application (*Figure 2.1*.)

3. Click the 'Next' button to continue the 'CD Update' process (see *Figure 2.2* below.) ****NOTE**: Do **NOT** disconnect Wi-Drive during this step.


Figure 2.1 - Updater


Figure 2.2 – Device Found

4. Click the 'Update' button to update the CD-ROM partition of the Wi-Drive (see *Figure 2.3*.)

Figure 2.3 – 'Perform CD Update' window

CD Update (for Mac) (…continued from page 6)

5. Click the 'Finish' button to complete the 'CD Update' process (see *Figure 2.4.*)

Figure 2.4 – 'Updater Status' window

6. Disconnect Wi-Drive from your Mac and turn on device to begin using.

– 'CD Update' Section Complete –

To verify that the update has been applied successfully, power on the Wi-Drive and verify the CD version listed in the Wi-Drive App located under the "Settings" Icon (see *Figure 3.1.*) You should see "**CD: v1.00.15**."

Figure 3.1 →