SM2280S3G2 Firmware Update Instructions (FW Rev. SAFM01.W)

Platform

PC with M.2 interface

System Preparation

- As a precaution, perform a backup of all your data to ensure no data is lost during the firmware update process
- Do not unplug power at any time during the firmware update
- Use only native M.2 sockets to perform upgrade. Do NOT use third party adapters
- Notebook users, please use AC power to prevent any power loss during firmware upgrade

Steps

- 1. Download the SM2280S3G2 Firmware Update ISO if you haven't already done so.
- Create bootable USB drive based on the SM2280S3G2_to_SAFM01.W.iso file.
 Note: There are a variety of software options available that will allow you to create a bootable USB drive based on an ISO file, but we've had success with Rufus: https://rufus.akeo.ie/
- 3. Boot from USB drive and select "live boot the Live system"
- 4. Follow the onscreen prompts to update target drive.
- 5. Update your drive. When successful, you will see:
 - a. The SSD Firmware has been updated on drive [serial number]
 - b. Power cycle is required to see and use the new code.
- 6. Shutdown system.
- 7. Power on system and use drive as normal.